

# ULTRASONIC CLEANER Instruction Manual >>>



#### **APPLICATION:**

Electronic factory, Car work shops, Industrial and mining area, Laboratories, Hospitals, Dental clinics, Watch shops, Optical shops, Jewelry shops, Mobile phone repair shops, and household use.

#### Ultrasonic cleaner

- Thanks for purchasing this machine.
- Read all instructions before operating the device.
- Please keep the manual for reference.

# Catalog

- Security precautions & Daily maintenance & Application description 1-3
- Product introduction & Product specification & Operation steps
   4-9

# Cautions

- Ensure the power supply is in rated range before power cable is connected. Refitting
  is strictly prohibited! Attention that the control panel will be croded by organic
  solution, strong acid and strong alkali.
- Ensure the earth wiring is well connected before starting.
- Activate key of system should be on position of "ON/OFF" button.
- Do not turn on machine if the tank is empty or the transducer will be damaged.
- Do not relocate the machine when fluid in the tank in case of overflow.
- Water-soluble liquid is suggested for bench top ultrasonic cleaner. Strong acid or flammability cleaner is strictly forbidden. If solvent type cleaner is added in tank, please stop working for a while after 30mins cycle.
- Do not use the machine in below environment.
  - The place where temperature change fiercely
  - The place where vibration or impact is strong
  - The place where water,oil or chemicals splash

- The place where humidity is too high and is easy to produce dew.
- The place where exists corrosive gas or dust
- The place where is filled with explosive and flammable gas



Do not work for long time when you use flammable liquid like alcohol! You will get better cleaning effect if cleaning solution is added in ultrasonic cleaner.

# Maintenance

- The unit must be opened by authorised specialised person only for maintenance and care of it.
- Clean the contaminant in the tank frequently.

# Trouble clearing

NO	Problems	Possible causes	Solutions	Remarks	
	No	A.Power supply not connect	A.Check and plug power switch.		
		B.Fuse broken	B.Check the fitted power supply and change the same specification fuse.		
1		C.Cable short circuit	C.Connect fitted cable or replace a new.		
		D.Transducer short circuit	D.Inquiry our after service engineer.		
		E.PCB Board broken	E.Check the broken part and replace it.		
		F.Other reasons	F.Inquiry our after service engineer.		
	Time control	A.Timer knob out of control	A.Loosen or tighten the screw.		
2	failure	B.Timer failure	B.Replace timer or digital panel.		
	ialiule		C.Inquiry our after service engineer.		
		A.Heater power switch linkage.	A.Check heating plug and connect well, Check outlet line with multimeler: if OK and resistance value is few hundred OHMs.		
	No heating	B.Fuse burn outl.	B.Change the same specification fuse.	Suggeation	
3		C.Heating pad burn out.	C.Replace the bad heating pad if open circuit.	50-60℃	
		D.Digital display board out of control	D.Check the broken part and replace it.		
		E.Other reasons	E.Inquiry our after service engineer.		
	Tomporet iro	A.Thermostat loosen.	A.Fasten the thermostat header.		
4	Temperature control failure	B.Thermostat tube broken.	B.Replace thermostat.		
'		C.Digital display of control.	C.Check the broken part and replace it.		
	Tallule		D.Inquiry our after service engineer.		
		A.Not Strong ultrasonic cleaning.	A.Connect ultrasonic button and adjust.		
		B.Too high too low liquid surfacel.	B. Adjust liquid into best urface.		
5	Not well	C.too high too low temperature.	C.Adjust temperature into the most fitted.	Suggeation 50-60°C	
	cleaning	D.Not suitable cleaning liquid.	D.Stop and switch off power supply, replace suitable liquid after the previous liquid cool down.	50-60C	
		E.Other reasons	E.Inquiry our after service engineer.		
6	Electric	C.Customer side not rounded.	C.Make sure the wire.		
	leakage	D.Machine not grounded.	D.Check if machine earth loosen.		
7	Other problems				

www.yunyisonic.com

# Ultrasonic application description

- The standard ultrasonic cleaners adopt high quality stainless steel plate with strong corrosion resistance and long lifespan, transducers with advanced connection sticking technology, high electroacoustic conversion efficiency and strong ultrasonic output, also equipped with automatic constant temperature heating device. Temperature range: 20-80°C.
- Suit for varies industries and objects cleaning, such as precision electronic parts, eyeglasses & clock parts, optical glass parts, hardware, jewelry, semiconductor silicon wafer, printer inkjet, medical instruments and electroplate parts etc.

Industry	The cleaning products and materials	Clear dirt
Semi-conductor	Integrated circuit, power tube ,silicon wafer, diode, lead frame, capillary, tray, etc.	Hards, etching oil, polishing wax, dust particles, etc,
Electrical& electronic machine	Tube parts, cathode ray tube, printed circuit board, quartzparts, electronic components, telephone switching equipment, speaker components, power meter, LCD glass, core iron parts, computer floppy disk, video parts, head, photo die mask, etc.	Finger print, powder, cutting oil, stamping oil, iron filings, polishing materials, walnut
Precision machine	Bearing, sewing machine parts, typewriter, textile, machine, optical mechanical device, gas valve, watches cameras, metal filter.	Machine cutting oil, iron filings, olishing powder, finger print, oil, grease, dirt, etc
Optical device	Glasses, lens, prism, optical lens, filter lens, glass device, film, optical fiber, etc.	Plastic resin, paraffin, finger printing, etc.
Hardware& machinery parts	Bearing, gear, ball, metal shaft parts, tools, adjustable valve and cylinder parts, burner, compressors, hydraulic press, gun and ultracentrifuge, city water faucet, etc	Cutting oil, iron filings, grease, polishing
Medical instrument	Medical instrument, denture, etc.	Iron filings. Polishing powder, oil, stamping oil, dirt, etc.
Electroplate	Galvanized parts, mold, stamping parts, etc.	Polishing scrap iron, oil, black iron shell, rust, oxidation shell, scrap iron, polishing powder, stamping oil, dirt, etc.
Car parts	Piston ring, carburetor, flow meter housing, compressor shell, electrical components, etc.	
Chemical fiber	Chemical or artificial fiber nozzle filter protector chemical fiber texture, etc.	Chemical colloid, glue, and other solid material. dust. Etc.

# D Series Product introduction



- 1 Lid 2 Stainless steel body
- 3 Stainless steel basket 4 Plug

# Product specification

Model	Capacity (L)	Frequency (KHz)	Ultrasonic Power (W)	Heating Power (W)	Tank Size (LxWxH mm)	Unit Size (LxWxH mm)	Temp. (°C)	Timer (Min)
YD0101	1.3	40	60	150	150x135x65	175x165x190	20-80	0-30
YD0201	1.3	40	120	150	150x135x65	175×165×190	20-80	0-30
YD0102	2.0	40	60	150	150x135x100	175x165x225	20-80	0-30
YD0202	2.0	40	120	150	150x135x100	175×165×225	20-80	0-30
YD0203	3.2	40	120	150	240x135x100	265×165×230	20-80	0-30
YD0303	3.2	40	180	150	240x135x100	265x165x230	20-80	0-30
YD0304	4.5	40	180	300	300x150x100	325x175x230	20-80	0-30
YD0306	6.5	40	180	300	300x150x150	325x175x270	20-80	0-30
YD0410	10	40	240	300	300x240x150	325x265x275	20-80	0-30
YD0610	10	40	360	300	300x240x150	325x265x275	20-80	0-30
YD0615	15	40	360	450	330x300x150	355x325x275	20-80	0-30
YD0815	15	40	480	450	330x300x150	355x325x275	20-80	0-30
YD0915	15	40	540	450	330x300x150	355x325x275	20-80	0-30
YD0822	22	40	480	600	500x300x150	530x330x280	20-80	0-30
YD1022	22	40	600	600	500x300x150	530x330x280	20-80	0-30
YD1222	22	40	720	600	500x300x150	530x330x280	20-80	0-30
YD1422	22	40	840	600	500x300x150	530x330x280	20-80	0-30
YD1522	22	40	900	600	500x300x150	530x330x280	20-80	0-30
YD1030	30	40	600	600	500x300x200	530x330x330	20-80	0-30
YD1230	30	40	720	600	500x300x200	530x330x330	20-80	0-30
YD1430	30	40	840	600	500x300x200	530x330x330	20-80	0-30
YD1530	30	40	900	600	500x300x200	530x330x330	20-80	0-30

# Operation steps



#### Check the machine

Plug the machine to be sure the machine will be in a state of electricity after start the power switch on the back.



#### Uncover the lip and fill the tank with tap water.

No water operation will damage the machine, please put the cleaning objects in the water. Fully immerse the part to be cleaned in the water, but do not over the MAX line.



#### Time setting

Clockwise rotate the time switch to chose the time you required between 0-30min. When the indicator light is on and make "ZIZI" sound, it shows ultrasonic works well.

Please take attention that anticlockwise rotate is forbidden.



#### **Heater setting**


Rotate temperature control knob to adjusted temp and start heating,  $40^{\circ}\text{C}-60^{\circ}\text{C}$  is suggested. (Heater is not suggesting for normal environment). When actual temp is lower than setting temp, heating function will auto start and the heat indicator light on. When temp reaches the setting temp, heat indicator light will off.



#### Finish work

Please do unplug the machine first after working, and then clean the tank. Be sure no liquid is in the tank if need long-term storage.

# S Series Product introduction



- 1 Lid 2 Stainless steel body
- 3 Stainless steel basket 4 Plug

# Product specification

Model	Capacity (L)	Frequency (KHz)	Ultrasonic Power (W)	Heating Power (W)	Tank Size (LxWxH mm)	Unit Size (LxWxH mm)	Temp. (°C)	Timer (Min)
YS0101	1.3	40	60	150	150x135x65	175x165x190	20-80	0-30
YS0201	1.3	40	120	150	150x135x65	175x165x190	20-80	0-30
YS0102	2.0	40	60	150	150x135x100	175x165x225	20-80	0-30
YS0202	2.0	40	120	150	150x135x100	175×165×225	20-80	0-30
YS0203	3.2	40	120	150	240x135x100	265x165x230	20-80	0-30
YS0303	3.2	40	180	150	240x135x100	265x165x230	20-80	0-30
YS0304	4.5	40	180	300	300x150x100	325x175x230	20-80	0-30
YS0306	6.5	40	180	300	300x150x150	325x175x270	20-80	0-30
YS0410	10	40	240	300	300x240x150	325x265x275	20-80	0-30
YS0610	10	40	360	300	300x240x150	325x265x275	20-80	0-30
YS0615	15	40	360	450	330x300x150	355x325x275	20-80	0-30
YS0815	15	40	480	450	330x300x150	355x325x275	20-80	0-30
YS0915	15	40	540	450	330x300x150	355x325x275	20-80	0-30
YS0822	22	40	480	600	500x300x150	530x330x280	20-80	0-30
YS1022	22	40	600	600	500x300x150	530x330x280	20-80	0-30
YS1222	22	40	720	600	500x300x150	530x330x280	20-80	0-30
YS1422	22	40	840	600	500x300x150	530x330x280	20-80	0-30
YS1522	22	40	900	600	500x300x150	530x330x280	20-80	0-30
YS1030	30	40	600	600	500x300x200	530x330x330	20-80	0-30
YS1230	30	40	720	600	500x300x200	530x330x330	20-80	0-30
YS1430	30	40	840	600	500x300x200	530x330x330	20-80	0-30
YS1530	30	40	900	600	500x300x200	530x330x330	20-80	0-30

# Operation steps



#### Check the machine

Plug the machine to be sure the machine will be in a state of electricity after start the power switch on the back.



#### Uncover the lip and fill the tank with tap water.

No water operation will damage the machine, please put the cleaning objects in the water. Fully immerse the part to be cleaned in the water, but do not over the MAX line.



#### Time setting

Default time is "05 00". Press "TIME+" once to increase time by 1minute. Press TIME-" once to decrease time by 1minute. Press ON/OFF after time setting and ultrasonic indicator light on, machine works follow the setting parameter and stop work when time counts down to "00 00", then indicator light off.



#### Temperature

Temperature display panel shows "50" and actual detergent temp. Press "TEMP+" to increase setting temperature by 1°C, press "TEMP-" to decrease setting temperature by 1°C. Press "ON/OFF" to start heating function and heater indicator on, actual temperature number will blazing by 1Hz Frequency during heating process, heater indicator light will off when temperature reaches the setting temperature.



# Degas


In the downtime, press "UTRASONIC" button 3 times within 3 seconds to enter the intermittent degassing mode, then the machine will work for 6 seconds and stop for 3 seconds to run alternately until the time end.



#### Finish work

Please do unplug the machine first after working, and then clean the tank. Be sure no liquid is in the tank if need long-term storage.

# W Series Product introduction



- 1 Lid 2 Stainless steel body
- 3 Stainless steel basket 4 Plug

# Product specification

Model	Capacity (L)	Frequency (KHz)	Ultrasonic Power (W)	Heating Power (W)	Tank Size (LxWxH mm)	Unit Size (LxWxH mm)	Temp. (°C)	Timer (Min)
YW0101	1.3	40	30/60	150	150x135x65	175x165x190	20-80	0-30
YW0201	1.3	40	60/120	150	150x135x65	175x165x190	20-80	0-30
YW0102	2.0	40	30/60	150	150x135x100	175x165x225	20-80	0-30
YW0202	2.0	40	60/120	150	150x135x100	175x165x225	20-80	0-30
YW0203	3.2	40	60/120	150	240x135x100	265x165x230	20-80	0-30
YW0303	3.2	40	90/180	150	240x135x100	265x165x230	20-80	0-30
YW0304	4.5	40	90/180	300	300x150x100	325x175x230	20-80	0-30
YW0306	6.5	40	90/180	300	300x150x150	325x175x270	20-80	0-30
YW0410	10	40	120/240	300	300x240x150	325x265x275	20-80	0-30
YW0610	10	40	180/360	300	300x240x150	325x265x275	20-80	0-30
YW0615	15	40	180/360	450	330x300x150	355x325x275	20-80	0-30
YW0815	15	40	240/480	450	330x300x150	355x325x275	20-80	0-30
YW0915	15	40	270/540	450	330x300x150	355x325x275	20-80	0-30
YW0822	22	40	240/480	600	500x300x150	530x330x280	20-80	0-30
YW1022	22	40	300/600	600	500x300x150	530x330x280	20-80	0-30
YW1222	22	40	360/720	600	500x300x150	530x330x280	20-80	0-30
YW1422	22	40	420/840	600	500x300x150	530x330x280	20-80	0-30
YW1522	22	40	450/900	600	500x300x150	530x330x280	20-80	0-30
YW1030	30	40	300/600	600	500x300x200	530x330x330	20-80	0-30
YW1230	30	40	360/720	600	500x300x200	530x330x330	20-80	0-30
YW1430	30	40	420/840	600	500x300x200	530x330x330	20-80	0-30
YW1530	30	40	450/900	600	500x300x200	530x330x330	20-80	0-30

www.yunyisonic.com

# Operation steps



#### Check the machine

Plug the machine to be sure the machine will be in a state of electricity after start the power switch on the back.



## Uncover the lip and fill the tank with tap water.

No water operation will damage the machine, please put the cleaning objects in the water. Fully immerse the part to be cleaned in the water, but do not over the MAX line.



#### Time setting

Default time is "05 00". Press "TIME+" once to increase time by 1minute. Press TIME-" once to decrease time by 1minute. Press ON/OFF after time setting and ultrasonic indicator light on, machine works follow the setting parameter and stop work when time counts down to "00 00", then indicator light off.



#### Temperature

Temperature display panel shows "50" and actual detergent temp. Press "TEMP+" to increase setting temperature by 1°C, press "TEMP-" to decrease setting temperature by 1°C. Press "ON/OFF" to start heating function and heater indicator on, actual temperature number will blazing by 1Hz Frequency during heating process, heater indicator light will off when temperature reaches the setting temperature.



#### Degas

After time setted, press "DEGAS" button to switch into degassing mode, then the machine will work alternately by semi-wave for 5s then full wave for 5s, it can exhaust air and prevent oxidation.



#### Semiwave

After time setted, press "ULTRASONIC" button to switch into full wave working. Press "SEMIWAVE" button, device switch into half wave working, ultrasonic power output reduce by half, but the ultrasound strength only reduce by 20%, this mode good for fine cleaning and low power operation requirements. (1.3L and 2L models, press "DEGAS" button 3times within 3s to turn on semiwave mode.)



#### Finish work

Please do unplug the machine first after working, and then clean the tank. Be sure no liquid is in the tank if need long-term storage.



# www.yunyisonic.com

# Professional teams provide design solutions for OEM/ODM

Optional size, power and functions

Frequency: 20/25/28/40/68/80/120/132/200 KHZ

Voltage: Single-phase110V/220V Three-phase220V/380V/415V

Material: SUS304/SUS316 T2.0/T2.5/T3.0

 Other functions: Filtration, Spray, Bubbling, Drying, Lifting, Throwing, Condensation, Slow-pulling, PLC (Programmable Logic Controller) system, etc.

# Yunyisonic Shenzhen Co., Ltd.

Add:1, Bitou 3 Industrial Pk 4 Rd, Baoan, Shenzhen, Guangdong Province, China

Tel: +86-755-27502790 Website: www.yunyisonic.com

E-mail: yunyisonic@yunyisonic.com